



PLEASE CHARGE FULLY BEFORE FIRST USE
RAPIDLY PRESS THE BUTTON UNTIL IT FLASHES TO UNLOCK THE BATTERY

VB ELEVEN PEN IS FOR EXTRACTS ONLY, NOT DRY LEAF
CAUTION: TEST YOUR ELEVEN PEN FIRST WITHOUT EXTRACTS

VB ELEVEN PEN INSTRUCTIONS

Before First Use:

- 1 - Fully charge the battery.**
- 2 - Unlock the battery by rapidly pressing the button.**
- 3 - Test the heater before loading material into it.**

1. Prior to first use, fully charge the battery. The batteries ship with a partial to full charge, so the charge time will vary and may not take long at all. When the red light goes out on the bottom of the battery, the charging is done and you can use the pen.
2. Unlock the battery by repeatedly pressing the button until the button light flashes. Once unlocked the button light should glow when pressed.
3. Prior to first use, test the heater skillet before loading with anything. If the heater glows red, the skillet is working and ready to be loaded. If the heater does not glow red, please do not load anything on it, immediately report the problem.

Everyday Use:

- 1 - Unlock the battery**
- 2 - Carefully load the heater skillet**
- 3 - Press button**
- 4 - Inhale**
- 5 - Repeat steps 3 & 4 as needed**
- 6 - Lock the battery**

Unscrew the cone from the skillet. Load the material directly onto the heater.

When loading the heater, it is always important to use care as the coil on any heater is the weak part. Also, be careful not to let the metal pick tool come into contact with the heater while it is being energized as this will cause an instant electrical short and break the heating wire.

If your material is thick enough, use your fingers to roll into a bb sized ball and lightly place it on top of the heater. Never press or force the material down onto the coil. You may push the battery to help the material melt into the coil.

Overloading the heater may prevent it from getting hot enough to vaporize oil.

After the material is loaded onto the heater, screw the cone back on. Press the button (light should glow) and start to inhale.

We recommend locking the battery when not in use. Lock the battery by repeatedly pressing the button until the button light flashes. Once locked the button light should not glow when pressed.

E-Juice/Liquids:

To prevent damage to the battery, do not attempt to use e-juice or liquid with the included skillet heater. Optional tanks are available to use e-juice or liquid with the VB Eleven pen.

VAPOR PEN CARE

- **Clean the heater**
- **Clean the threads and contacts**
- **Always use the provided case**

Cleaning the Heater Skillet:

The best way to clean the skillet is to use the heater like a self cleaning oven. Try to burn off any remaining residue by tilting the battery base upside down (usb port up) and pressing the button until it flashes. Repeat as needed.

You can also repeatedly dunk the skillet upside down in a small pool of iso alcohol (use only 91% or higher). **The outer finish may wear off if skillet is submerged in strong alcohol.** Let the alcohol evaporate then attach the heater to the battery and heat the coil to burn off any remaining iso.

Skillets are consumable and will need to be replaced periodically.

Cleaning Threads & Contacts:

Dirty threads or contacts can damage or prevent the pen from working properly.

To prevent alcohol from running off into the electronics when cleaning the battery base, **turn the battery upside down** (usb port up).

Use iso alcohol (91% or higher recommended) and a cotton swab to clean the threads on the skillet, battery base, cone, plus contacts on the battery base and heater.

Use a circular motion to clean the inside threads and contact on the battery base.

PROTECT THE PEN FROM DAMAGE

If you carry your vapor pen in your pants pocket please use the provided case or unscrew the battery. Your pen could break when you sit down, which is not covered by the warranty.

CAUTION

In the event that the battery gets broken open please **DO NOT stuff the parts back together**. If the wires cross, this could cause the sparks and fire. Batteries that are broken open are not covered under warranty.

Safely dispose of the battery following your local rules for batteries disposal.

Improper use of the VB Eleven pen may result in serious injury.

WARNINGS & DISCLAIMERS

This device has hot surfaces to evaporate the active ingredients and these surfaces should not be touched during use.


The VB Eleven Pen is only to be used with the recommended vaporizing medium (herbal extracts). The use of other substances may produce toxins or damage to the device.

The statements on these instruction pages have not been evaluated by the Food and Drug Administration. The product listed is not intended to diagnose, treat, cure or prevent any disease.

This document is for informational purposes only. We are not advising or prescribing treatments for any specific medical condition or for any specific use. Consult your doctor before starting any regimen.

This device is not intended for use by persons (including any person under the age of 18) with reduced physical sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the device by a person responsible for their safety.

ELEVEN PEN PARTS



CONTENTS OF THE KIT

- Battery with Built-In Micro USB Charger
- Heater Skillet
- Cone
- Mouthpiece
- Micro USB Charging cable
- Case

VAPORBROTHERS VB ELEVEN PEN WARRANTY

Vaporbrothers, Inc. makes every effort to assure that our products meet high standards, and warrants to the purchaser that the VB Eleven Pen is free from defects in materials and workmanship. Vaporbrothers will replace any defective VB Eleven component or accessory, provided the customer returns the product to us and gives us an opportunity to verify the defect by inspection. Vaporbrothers is not responsible for damage caused by misuse or abuse. Please note we are continually improving our warranty, so the terms may change without notice.

TERMS & CONDITIONS

Battery: 1 year replacement for electronic defects. Return shipping to customer is free for the 90 days after purchase within the U.S.A. Between 90 days to 1 year, there is a \$14 replacement fee. Applies to date of original purchase. Proof of purchase required.

Heater: 90 day replacement for defects on unused heaters only. We replace heaters that fail out of the box only. Heaters containing oils cannot be accepted for replacement. Return shipping to customer is free within the U.S.A.

All other components: (except accessory glassware): 90 days replacement for defects. Return shipping to customer is free within the U.S.A. Please report any problems in the first 3 days after receiving order.

Proof of purchase is required. The terms above are expressed in time from the original purchase date. Replacement of a defective part does not extend the warranty period.

Additional terms: Shipping outside the U.S.A. will be an additional charge and customer is responsible for all postage costs.

HOW TO OBTAIN WARRANTY SERVICE

If you believe your VB Eleven Pen is not working correctly, please check to ensure that the pen is not locked or that the source of the problem isn't something else, such as a broken usb adapter or charger.

In the event the VB Eleven Pen is defective, please contact support@vaporbrothers.com or call **(844) 828-2737**.

No registration, serial number, or RMA is required from you to use this warranty. Just let us know what you think is the problem and we will give you instructions on how to get the defective part replaced as soon as possible.

Vaporbrothers® is a registered trademark of Vaporbrothers, Inc.

Copyright © 2020 by Vaporbrothers, Inc. All rights reserved.

Made for Vaporbrothers by custom manufacturer in China

5271_REV-01_ART_VAPORBROTHERS-VB11-INSTRUCTION.pdf